

TECHNICAL DATA SHEET

Order No. **458-1065**

Item/Model **SARO Plate Warmer
model SYLT 120**

GTIN **4017337048731**



- **Material: stainless steel**
- **Capacity for 120 plates with a diameter of up to 30 cm**
- **On / Off with light "On"**
- **Power cable with safety plug**
- **Weight: 46,5 kg**
- **Dimensions: W 800mm x T 460mm x H 870mm**
- **temp. +5/+90 °C**
- **Conn.: 230 V - 50 Hz - 1,5 kW**

Origin Portugal

customs tariff no. 85167970

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827

SAFETY & WARNING INSTRUCTIONS

Order No. **458-1065**

Item/Model **SARO Plate Warmer
model SYLT 120**

GTIN **4017337048731**



Safety and Warning Instructions

- Only place the device on a stable, horizontal, and heat-resistant surface.
- Ensure that the mains voltage corresponds to the specifications on the equipment properties plate.
- Children and unauthorized persons must not operate the device or be unsupervised near it.
- The device surfaces can become very hot during operation – risk of burns.
- The device must not come into contact with or be operated near flammable materials. If necessary, the installation area should be lined with heat-resistant material.
- Never clean the device with a water jet or immerse it in liquids to prevent the risk of short circuits and electric shock.
- Before cleaning, maintenance, or extended periods of non-use, turn off the device, disconnect it from the power supply, and allow it to cool completely.
- Ventilation openings must not be blocked or covered to avoid overheating.
- Do not operate the device with a damaged cable or plug. In case of damage, stop operation immediately and contact qualified personnel.
- Repairs must only be carried out by qualified personnel using original replacement parts.
- The device must not be operated with timers or external control systems that automatically turn it on.
- Before plugging in or unplugging the power cord, ensure that the main switch and temperature control are set to "Off."
- Ensure that the power cord does not come into contact with hot parts of the device or run over sharp edges.
- The device is intended only for its designated purpose: heating and keeping empty plates warm.
- If the device comes into contact with water, immediately disconnect it from the power supply and dry it thoroughly before reuse.
- Dispose of packaging materials safely and keep them out of the reach of children, as they pose a choking hazard.

Origin Portugal

customs tariff no. 85167970

Dealer Saro Gastro-Products GmbH, Sandbahn 6, 46446 Emmerich am Rhein, GERMANY

Eingetragen: Kleve HRB 2768 * Geschäftsführer: Dominique de Charry, Aloys de Charry
ID-Nr. DE 120061194 * St.-Nr. 116/5718/0194 * ILN 4017337000005 * WEEE-Reg.-Nr. DE 58229827